## **HP 3000 Computer Systems**

# SERIES 64/68 A/B SYSTEM BLOCK DIAGRAMS AND ASSEMBLY DRAWINGS MANUAL For HP Repair Use Only



19447 PRUNERIDGE AVENUE, CUPERTINO, CA 95014

# FEDERAL COMMUNICATION COMMISSION RADIO FREQUENCY INTERFERENCE STATEMENT

The United States Federal Communications Commission (in Subpart J, of Part 15, Docket 20780) has specified that the following notice be brought to the attention of the users of this product:

"Warning: This equipment generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instructions manual, may cause interference to radio communications. It has been tested for compliance with the limits for Class A computing devices pursuant to Subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference. Operation of this equipment in a residential area is likely to cause interference in which case the user at his own expense will be required to take whatever measures may be required to correct the interference."

#### NOTICE

The information contained in this document is subject to change without notice.

HEWLETT-PACKARD MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Hewlett-Packard shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance or use of this material.

Hewlett-Packard assumes no responsibility for the use or reliability of its software on equipment that is not furnished by Hewlett-Packard.

This document contains proprietary information which is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced or translated to another language without the prior written consent of Hewlett-Packard Company.

## LIST OF EFFECTIVE PAGES

The List of Effective Pages gives the date of the current edition, and lists the dates of all changed pages. Unchanged pages are listed as "ORIGINAL". Within the manual, any page changed since the last edition is indicated by printing the date the changes were made on the bottom of the page. Changes are marked with a vertical bar in the margin. If an update is incorporated when an edition is reprinted, these bars and dates remain. No information is incorporated into a reprinting unless it appears as a prior update.

Third Edition	•	 •	•	• •	•	•	•	•	•	•	December	1984
Effective Page	es											Date
4 7 7											DEC	1004

## PRINTING HISTORY

New editions are complete revisions of the manual. Update packages, which are issued between editions, contain additional and replacement pages to be merged into the manual by the customer. The date on the title page and back cover of the manual changes only when a new edition is published. When an edition is reprinted, all the prior updates to the edition are incorporated. No information is incorporated into a reprinting unless it appears as a prior update.

First Edition . . . . . . . . . . . . . . . . . . AUG 1982
Second Edition . . . . . . . . . . . . . . . . . FEB 1983
Third Edition

# **PREFACE**

This document contains block diagrams and assembly drawings for the HP 3000 Series 64/68 A/B Computer Systems.

Diagrams and drawings that apply only to the Series 64/68 A are labeled "A" on the first page of each section in the column labeled "SYSTEM". Those that apply only to the 64/68 B are labeled "B" in the "SYSTEM" column. All other diagrams and drawings are labeled "A/B" and apply to both systems.

The computer block diagrams appear in the first tabular section, followed by the assembly drawings in the second section. Each section begins with its own table of contents.

v


# SYSTEM BLOCK DIAGRAMS


SECTION


This section provides system block diagrams for the HP 3000 Series 64/68 A/B computer system. The diagrams appear in order as listed below.


### CONTENTS


DIAGRAM	SYSTEM	PAGE
CPU and Cache Memory Module	A/B	1-2
Main Memory Module	A/B	1-3
Intermodule Bus	A/B	1-4
Intermodule Bus I/O Adapter	A/B	1-5
I/O System Module	A/B	1-6
Diagnostic Control Unit/Power System Control	Α	1-7
Diagnostic Control Unit/Power Distribution Monitor	В	1-8
CPU Block Diagram	A/B	1-9
RALU Block Diagram	A/B	1-10
CTLA Block Diagram	A/B	1-11
CTLB Block Diagram	A/B	1-12
SKSP Block Diagram	A/B	1-13
VBUS Block Diagram	A/B	1-14
CIR Block Diagram	A/B	1-15
WCS Block Diagram	A/B	1-16























































DRIVER FLASHER	FV8 MONIFOR DRIVER	OT BE EANFAIL	PDM  PSCINT(L)  RESET DCURESET	TO CPG { ECLEPTION   FON   FON	PSCINT(L)  PSCINT(L)  DCURESET  DCURESET
AP)	ATABUS	DISABLE UTDOWN	PFA 1 PFA 1 PFA 1 PFA 1 PON  I SEC INT  DATA SUS		BLIE 19.66 EST MH7 WITCH OSC C  COL VARTOLL  VARTOLL  VARTOLL  VARTOLL  UARTILL  RECONSTRUCT  RE
MA BATTERY CURRENT	PRODUCTION TEST FIXTURE  TP TP  VOLTAGE I/O TR  POWER MODULES			FROM EACH 27 PCA ON CPU BACKPLANE  DATACON SWITCHIN CIRCUITS  LOCAL CONSOLE  REMOTE CONSOLE	ATP  REMOTE MAINT CONSOLE



























# SYSTEM ASSEMBLY DRAWINGS


SECTION

This section provides assembly drawings for the HP 3000 Series 64/68 A/B computer system. The drawings appear in order as listed below.


#### **CONTENTS**

P/N		DRAWING	SYSTEM	PAGE
30140	-60023-51	AC Distribution	Α	2-2
11	60027-3	Battery Control Module Assembly	Α	2-3
11	60027-51	Battery Control Module Schematic	Α	2-3
	60036-1	Fuse Wiring and Assembly	Α	2-4
**	60048-2	DCU/Datacomm Assembly	Α	2-5
	60049-2	AC Sense Transformer Assembly	Α	2-6
u	60049-51	AC Sense Transformer Schematic	Α	2-6
н	60063-1	I/O Plenum Fan Tray Assembly	A/B	2-7
"	60066-1	CPU Plenum Assembly	A/B	2-8
	60066-2	CPU Plenum Fan Tray Assembly	A/B	2-9
#1	60070-1	System Display Panel Assembly	Α	2-10
11	60071-1	Battery Module Assembly	Α	2-11
**	60081-1	Cable Assembly-Modem Jumper	A/B	2-12
u	60082-1	Flat Cable Assembly-IOB/IMBI	A/B	2-13
n	60100-2	Datacomm Cable Assembly	В	2-14
"	90001-1	Mainframe Final Assembly	Α	2-15
u	90001-2	Interbay Cabling	Α	2-16
	90001-3	I/O Bay Final Wiring	Α	2-17
н	90001-6	Mechanical Assembly-CPU Bay	Α	2-18
**	90001-7	Mechanical Assembly-I/O Bay	Α	2-19
	90001-15	Assembly-Power Supply Units	Α	2-20
"	90001-18	PCM & ISO Transformer MTG. IO	Α	2-21
**	90001-23	CPU Bay Wiring, Step #4	Α	2-22
"	90001-24	PCM Mounting & Final Wiring	Α	2-23
n	90002-1	AC Wiring Diagram	Α	2-24
"	90002-2	Power System Control Wiring	Α	2-25
н	90002-3	CPU I/O Backplane Wiring	Α	2-26
11	90032-1	Assembly-AC Unit, Cable Mount, & Transformers	В	2-27
11	90032-2	Assembly-CPU Bay	В	2-28
u	90032-3	Assembly-I/O Bay	В	2-29
u	90032-4	Assembly-Bus Bars	В	2-30
	90032-5	CPU Bus Bar	В	2-31
п	90032-6	CPU Cabling-Step #1	В	2-32
	90032-7	Interbay Cabling/CPU Cabling-Step #2	В	2-33
11	90032-8	CPU Cabling-Step #3	В	2-34
11	90032-9	Interbay Cabling/High Voltage Distribution	В	2-35
н	90032-10	Assembly-System Cables and Labels	В	2-36
	90032-11	Final Assembly	В	2-37
11	90034-1	Control & Monitor Signal Distribution	В	2-38
"	90034-2	Low Voltage D.C. Distribution	В	2-39
"	90034-3	AC/DC High Voltage Distribution	В	2-40








PCA - BCM ASSY. DWG.	HEWLETT & MCKARD
NEST ASSESSE.	30140-60027
France 2:1	D-30140-60027-3




PCA- BATTERY CONTROL MODULE	C. HEWLETT PACKARD		
30140A	30140-60027 PART NUMBER		
FINISH BOALE	7-30140 -60027 -51		












PCA-AC SENSE TRANSFORMER ASSY DWG	. O.Z.W. Eth Professors
	30140-60049
	(C-30140-60049-2)


PCA - AC SENSE TRANSFORMER TITLE SCHEMATIC DOI:-	CT HEWLETT PACKARD			
30140-60023	30140-60049			
PINISH SCALE	C-30140 - 60049-5			




MAINFRAME - SERIES 64 VO PLENUM FAN TRAY ASSEMBLY	HEWLETT PACKARD			
30140 A	30140-60063			
PRIME NONE	D 30140 -60063-1			









PACKARO
PART HARRIST
D-30140-60070-



MAINFRAME - SERES GE BATTERY MODULE ASSEMBLY	
30140A	30140-60071
	D 30140-60071-4







# NOTES:


- A 1. MARK P1 AND P2 ON HOUDS AS SHOWN, PIN1 SIDE, + HP logo PER DWG. A-5955-1724-2.
- 2. STRIP OUTER INSULATION I" BOTH ENDS.
- 3. STRIP WIRES 3/16" BOTH ENDS.
- 4. USE JUMPER WIRE ITEM (6). AND SHRINK TUBING ITEM (9) IN CONNECTING SHIELD.
- 5. COYER ENDS OF UNUSED WIRE (WHT/BRN) WITH SHRINK TUBING ITEM .
- 6. ASSEMBLE CONNECTOR HOODS PER DWG A-5955-1724-1.

9	0.2 FT	TUBING - HEAT S	HRWK 0.093D	0890-0706		
8	0.3 PT			3150-0447		
7	4.5 FT		CONT 26 AWG	8120-2722	L	
6	2	CABLE TIE		1400-0249	L	
5	2	HOOD - CONN S	M-D25	1251-4891		
4	10	CONTACT - CONA	FEM CRIMD	1251-5781		
3	1	CONN - SM-D 2		17.51-2416		
2	10	CONTACT - CON!		1251-5780		
1	<u> </u>	CONN - SM-D 25		1251-2417		
ITEM	OTY.		ESCRIPTION	MAT'L-PART NO.	MAT'L DWG. NO.	MAT'L-SPEC.
			CABLE A		(A) HE	EWLETT ACKARD
					30140 - Part number	
					C-30140 -	60081-1





FCA-10B/IMBI	PACKARD
HEXT ASSELVELY 30140 A	30140-60082
PINISH SCALE FULL	-30140-60082-1






			NEXT ASSEMBLY	2140 A	PART NUMBER  -30140 -	99991
	.,		MAINFRAME TITLE FINAL A	- SERI <b>ES 64</b> SSEMBLY	PERM. PRINT	EWLETT
1	ITEM	QTY.	MATERIAL-DESCRIPTION	MAT'L PART NO	MAT'L-DWG, NO.	MAT'L SPEC.
	一	<del>                                     </del>	ASSY' - CPU BAY	REF.	D-6	
. ت	_ <u></u>	1	A554' - 1/0 BAY	REF	D-7	
is.	3	8	BOLTS 14-20X 1.50 HEX	2940-0137		
	-7-	- B	LK WASHER - WHEL	2190-0032	<b></b>	
-	<u>6</u>	8	WASHER FLAT 14	3050-0275		
-	-7-	12	SCR. 8-32 X 44 PH W/L COVER-TOP CPU BAY	2510 - 03 <i>01</i>		
ŀ	_8	12	WASHER . 172 I.D. FLAT	3050 - 0139	<b></b>	
1	9	1	COVER - TOP 1/0 BAY	4040-1792		
1	10		PANEL - EXT. SIDE (L)	30140-00068		
	-11	1	PANEL - EXT. LT. FRONT	30140-00039		
	12		PANEL - EXT. RT. FRONT	30140-00036		
	13	2	PANEL-EXT, CENTER FT	30140-00042		
Ī	14		PANEL-EXT, RT, REAR	30140-00047		
- 1	15		PANEL-EXT. LT. REAR	30140-00050		
ľ	16	i	PANEL - EXT SIDE (R)	30140-00045		
ادء	17	ī	PANEL - EXT. REAR CAPLE EXIT	30140-00052		
A A	18	2	SCREEN - ESD	1600-1291-		
1	19	36	SCR. # 10-32 X . 50 PH W/L	2680-0274		
ŀ	20	36	WASHER - # 10 FLAT	3050 - 0226		
ŀ	21	4	PLATE - 1/3 BLANK	30090-00016		
	22	14	PLATE - FULL BLANK	20090-00022		
A	23	2	GIC ASSY' PLATE	30090-00017		
t	24	.80	4R. 6-32 × .38	2360-0359		
-	25		DELETED			
A	26		DELETED			
2	2.7	2	GROM MET	0400-0082	1	









- NOTES:

  1 HOLD ITEM ② UP AGAINST UNDERSIDE OF FRAME MEMBER WHILE TIGHTENING HARDWARE.
  2 INSTALL ITEM ④ BEFORE MOUNTING ITEM ⑤
  3 TIGHTEN CAPTIVE SCREW TO SECURE ITEM ⑦ AFTER INSERTION.
  4 INSERT BOTTOM OF ITEM ② IN TROUGH AND SECURE AT TOP WITH CLIPS. (ITEM ③)
  AIR FLOW ARROW ON ITEM ③ SHOULD POINT INTO THE CABINET.
  5 SECURE RIGHT SIDE OF ITEM ⑧ FIRST, THEN INSTALL ITEM ⑨
  LEFT SIDE USING COMMON HARDWARE.
- 6 INSTALL PSC-PCB- ITEM (27) ON ESD GROUND MAT.
- 7 INSTALL MEM @ ONLY ON THE TWO TOP BRACKET CUTCUTS AND EDGE OF CARD CAGE, AND ON SWITCH INTO PLATE ITEM (1)
- B AFTER ATTACHING THE MEMORY BACKPLANE (38), VEKIFY THAT A GAP (APPRIX. . 05" THICKNESS OF DIM. ) EXITS BETWEEN THE CONN. PINS AND THE BACKPLANE.

42   1   COVER - WIR     42   1   WIR ING DICT     41   1   STIFFENER -     40   4   SCR. 4 - 40     39   1   ABEL - 10     38   PLATE - CPU     37   1   COVER - WIR IN     36   1   WIR ING DUCT     35   NASY - PLEND     35   NASY - PLEND	LAT #4 -#4 HEL312 L PH POZ NG DUCT, CPU E CENTER C.C. <.312 L FH T, CPU CC	3P 30140-0008	9 3 1 87	
44 12 SCR. 4-40 x 43 1 COVER - WIR 42 1 WIRING DIC 41 1 STIFFENER- 40 4 SCR. 4-40 x 39 1 (ABEL-104) 38 1 PLATE - CPU 37 1 COVER - WIRING DUC 36 1 WIRING DUC 35 1 MAGY-REAU	312 L PH. POZ NG DUCT, CPU E , CPU BACKPLI CENTER C.C. (312 L FH T, CPU CC	1. 2200-014 BP 30140-0008 N 30140-0008	37	
41   STIFFENER- 40   SCR 4-40 > 39   LABEL-IDEN 38   PLATE-CPU 37   COVER-WIRT 36   WIRING DUCT 35   NASY-REW	,CPU BACKPLI CENTER C.C. (.312 L FH T ,CPU CC	N 30140-0008	-	
39   LABEL-IDEN 38   PLATE-CPV 37   COVER-WIR!/ 36   WIRING DUCT 35   RES'Y-RENU	T, CPU CC		78	
36   WIRING DUCT 35   RESTY-RENU	CC LAREL MT	2200-0166 7121-1939	9	
JO NENU	VG DUCT, MEM B - MEM. BACKPLN	P 30140-0008	5	+
34 2 FILTER - AIR	H. P. SUPPLIES , 9×29	REF. 3150-0389	D-9	
32   ASS'Y -SYS	TEM DISPLAY PANE	1600-1087 4 REF.	D-8	
30 70 WASHER#		3050-0228	3	
28 I PCA-MEMO	RY BACKPLANE	30140-6002		
26 2 WASHER - # 25 20 SCR. 8-32× .4		2510-0301 2510-0301	6	
24 20 WASHER-F	LAT #8 RAP - P.S.	30,50-0139 30140-00076		+==
22 18 SCR 6-32 x 3 21 3 SWITCH-THE	RM. 122° F CL	2360-0359 3103-0088	-	
19   PLATE - SWITCH 18   CARD CAGE	RM. 104 FCL TH MTG.	3103-0089		
17 1 ASS'Y-FAN 16 1 DUCT - CABL	TRAY, CPU	7101-0582 REF. 30140-00014	D-10	
15   ASS'Y- PLE	NUM CPU L-CPU PLENUM	RFE	D-I1	
13   PAN - DRIP, C 12   ASS'Y - BAT	TERY MODULE	4040-1875 REF.	D-14	
10 ASS'Y-POWER	R SUPPLY UNITS	REF.	D -15 D-15	62971M
8 - ASS'Y- POWER	R SUPPLY UNITS	REF.	D = 15 D = 15	62970 M 63901F
6 120 WASHER - FLI 5 140 SCR. 10-32 X	SO PH WIL	30140-00072 3050-0226 2680-0274		
4 2 ASS'Y-COUF 5 1 PLATE-CON	OWER SUPPLY TRAY NECTOR CFU RH	REE	D-16	<del></del>
I I FRAME - C.P.	TOP COVERS	30140-00001 7101-0580 MATL-PARTNO	MAT'L DWG NO	MAY L SPEC



	47	2	SCREW	2680-0099		
	46		POWER CORD	30140-60090		
	145		DELETED			
•	44		DELETED	<del> </del>		<del> </del>
,	43	-	STRAIN BELIEF	0100= 1190		<del></del>
-	4Z	4		0100-1140		<del> </del>
	41	2	WASHER # 10 STAR SCR 10-32X-60 FH	2190-0070 2680-0106	<del> </del>	<del> </del>
	40	1 -	PLATE - ANGLE	3040-00101		<u> </u>
		<del>                                     </del>	GND STRAP	<del> </del>		<del>                                     </del>
	39 38	A/R	GROMMET - CHANNEL	30070-60062 0400-0082		+
	37	8	WASHER - FLAT #4	3050-0229		
	36	8	LKWASHER - #4 HELICAL	2190-0108		
	35	8	SCR. 4-40 x 312 L P.H. POZI			
	34	3	WASHER - FLAT # 8	3050-0139		
	<b>3</b> 3	3	SCR. 8-32 × .44 PH W/L COVER-WIRING DUCT, 1/0 BAY	2510-0301	2	
	31	<del></del>	WIRING DUCT - 1/0 BAY	30140-00082	ļ	·
	30		BRKT - MTG. CABLE PANEL	30140-00073		
	29	Ť	PLATE - CONN. I.O. BAY	30140-00071		1
	28	_/_	PLATE - CONN. I.O. BAY LABEL - IDENT, 1/0 CC	7/21-1940		
	27	_3_	SCR 4-40 x 312 FH	2200-0166		
	26		PLATE-MTG. LABEL 1/0	30140-00081		
1	<u>25</u>	2	SWITCH-THERM. 122 F CL SWITCH-THERM. 104 F CL	3103 - 0088 3103 - 0089		
	23	<del>-</del>	PAN-DRIP 1/0 BAY	4040-1874		
	22	2	JUNKTION PANEL	7-011-0 00022		
	21	1	JUNCTION PANEL BLANK	3040-00023		
	<u>20</u> 19	2	CLIP-SPRING SUPPORT JUNCTION FAMEL	1600-1087 30140-00024		ļ
	18		PLA - DUAL 1/0 BACKPLANE	30140-60021		
-	17	2	CHANNEL-RFI, TOP/BOTTOM	30140-00005		
ļ	16		AIR FILTER- SPLENUM SUPPORT - P.S. TRAY	3150-0590		
	15	2	CARD CAGE - 24 SLOT	30140-00021 7101-0583		
	13	<del></del>	ASSY-FANTRAY & PLN	REF.	D-12	
ı	12		DUCT, CABLE - 1/0	3040-00019		
A)	4	42	MASHER #6 FLAT	REF.	D-13	
<u>ده</u>	- <u>0</u>	72	32 X 6-32 X . 575 W/L	3050-0228 2360-0359		<b></b>
	8	2	ASSY-POWER SUP UNITS	REF.	D-15	6297/M
	-7	1	ASSY-POWER SUPSHELF	REF.	D-17	
4	5	30 95	SCR. 6-32 X.44 PH W/L WASHER # 10 FLAT	<u>2360-0300</u> 3050-0226		
Ā	4	_/52		2680-0274	<del></del>	
-	3	13	BRACKET- MTG TOP	30140-00001		
	-2-	1	POVER CONTROL MCD.	REF.		30140-60023
-	_ <u> </u>	977	ASSY I/OFRAME & X FORMER	REF.	D - 18	MAT'L SPEC
-				E - SERIES 64		
			MECHANICA	L ASS'Y-	PERM. PRINT	EWLETT ACKARD
				0140 A	PART NUMBER	
			FINISH	NONE	D 30140 ·	90001-7




- I ITEM (9 VIST ON BETWEEN EZ 1 E3.


  REMAYE THE FLATHLAD SCHEVS WHICH
  COME VITH THE POWER SUPPLY AND
  REPLACE VITH ITEM (8) AS SHOWN.


  3 REMIOVE SCREAT (164) ON 970 P71

	30	140 A		
	ASS'Y- POR	VER SUPPLY S	PERM. I MILE	EWLETT ACKARD
MATERIAL E	ESCRIPTION	MAT'L PARTIED	MAT'L-0008 NO	MAT'L STORE
		62970M		
	PLY - NET			
		<u> </u>		
	PCA - POVER DE PACKET - PXE VAQUER SE X X X X X X X X X X X X X X X X X X	PCA: POWER DIT: QIP PCA: POWER DIT: POB ERACKET - PCB MITTE WASHER BY FLAT ANDLE - POWER SUPPLY CAREN TO SIX - 60 PH GUIDE - PS DC POWER SUPPLY - NJ DC POWE	PICA - POWER DIST - 239 SOUR-GOLDS PICA - POWER DIST - POB  PICA - POWER DIST - POB  PICA - POWER DIST - POB  PICA - POWER SUPPLY  LANDLE - FOWER SUPPLY  LANDLE - POWER SUPPLY  LANDLE	PCA: POWER DIST: Q39 SOME-COSTS PCA: POWER DIST: POB SOME GOSTA  ERCACKET - PCB MTTS SOME GOSTA  ERCACKET - PCB MTTS SOME GOSTA  ANDLE: BY FLAT SOS-0228  ANDLE: POWER SUPPLY NON-00013  CCREW 16-32 x -60 FH 2400-0013  CCREW




NOTE: STRAPPING DEPENDS ON INPUT VOLTAGE.







PCM & 14	ME-SERIES ( 50, X-FOLMER MTG, IO	
HEXT ASSEMBLY	30140 A	PART NUMBER
F1010\$01	SCALE -	D-30140-90001-18





	AY WILING EP#4	HEWLETT PACKARD
MEXT ABBEHISL	30140 A	PART NUMBER
Finish	SCALE NOVE	(-30140 -90001-23





	MAT'L DWG NO	MAT'L SPEC
PCH MOUNTING &	HEWLETT PACKARD	
HERT ABBEHBLY 30140A	PART NUMBER	
FINISH SCALE NONE	3-30140-	90001-2










































MO	DLLE	. Е	3 INTERFACE
В	MQG	MEM BIP	SIGNAL
P2- 4	P3-8		BATT. SOUPCE
PZ-5	P3-9		BATT. SOURCE
7 -S9	P3-10		BATT. RETURN
P2-8	P3-11		BAT I. RETURN
P2-20	P3-2		BATT. CONNECT
P2-10	P3-13		BATT. CONNECT RETURN
21-59	P3-5		CHARGER MOD ALARM
P2-2	P3-4		CHARGER ALARM RTN
P2-13	P3-1		CHARGER SHUT DOWN
P2-3	P3-15		CHARGER SHUTDOWN RTN.
P2-14	P3-6		CHARGER OUT CURRENT
P2-16	P3-19		BATT VOLT MONITOR
P2-17	P3-7		BATT CURRENT
P2-	İ		
15-19			CHARGER INTERLOCK
P4-1	P3-18		5B OUTPUT CURRENT
P4-12	P3-17		5B MODULE ALARM
P4-2	P3-12		5B MODULE ALARM RTH
	P3-16		5B MOD. SHUTDOWN
–	P3-3		5B MOD SHUTDOWN RTN.
P4-15		P5-1	5B SENSE
P4-16	1	P5-2	SB SENSE RETURN
P4 -	1		1
9-5	i		SB INTERLOCK



	7
A	C UNIT INTERFACE
AC PD	1 BAY SIGNAL
P5-1 P4-1	2 RECTIFIER FAIL ALARM (RFA)
P5-3 P4-	OVERTEMP ALARM (OT)
P5-4 P4-	O FAN POWER ALARM
P5-2 P4-	
P5-5 P4-	
P5-6 P4-	11
P5-B P4-	
P5-9 P4	1 05-01
P5-7 P4-	
P4	1 P24-2 LOW TEMP. SENSE
P4-	2 PZY-1 HIGH TEMP. SENSE


MODULE SET D INTERFACE				
DI	DS	MQq	LIO	SIGNAL
PZ-11	P2-1			5V SENSE RTN
P2-1			P21-2	SV SENSE RTN
P2-18	8-59			5 V SENSE
P2-8			P21-1	5V SENSE
P2-6	P2-16			5V LO MARGIN
P2-16		P9-14		SV LO MASGIN
P2-7	P2-17			SV HI MARGIN
P2-17 P2-70	P2-10	P9-13		SV HI MARGIN CURR SHARE
12.0	12-10			
P2-12		P9-2 P9-3	ı	DI MOD ALARM DI MOD ALARM COM
P2-2 P2-13		P9-1	1	DI MOD SHUTDOWN
P2-3		P9-6		DI MOD SHUTDOWN COI
P2-14		P9-11	ļ	DI OUTPUT CURR. DI INTERLOCK
P2 15-19				DI INTERLOCK
P2	t			D2 INTERLOCK
15-19				
	20.13	m -		N2 MOD ALARM
		P9-5 P9-15	1	DE MOD ALARM COM
	P2-13	P9-4	l	DZ MOD SHUTDOWN
		P9-10		DZ MOD SHUTDOWN CO DZ OUTPUT CURE.
	172-14	טו-כיון	ĺ	DL GUITOT CORE.


### NOTES:

- 1. 30140-60051 CABLE.
- 2. 30140-60116 CABLE.
- 3. 30140 60123 CABLE.
- 4 30140-60125 CABLE.
- 5. 30140 60127 CABLE.
- 6. 30140 60128 CABLE.
- 7. 'BAY TEMP' REFER TO J24 OF 30140-60055 CABLE.
- B. MODULE PART NUMBERS ARE STAMPED ON THE SIDE OF THE MODULE, NOT THE BACK AS SHOWN.
- 9. THE SSDP-B CONNECTORS ARE LOCATED ON THE BACK OF THE SSDP-B ASSEMBLY.
- 10 30140 600 52 FLAT CABLE.
- THIS DRAWING 13 INTENDED FOR
  POINT TO POINT SIGNAL IDENTIFICATION
  DNLY. REFER TO THE 30146-90032.
  DRAWINGS FOR CABLE ROUTING
  AND OTHER ASS'Y DWGS.

ITEM OTY.	MATERIAL DESCRIPTION	MAT'L PART NO	MAT'L DWG NO	MAT'L SPEC.
		# MULTUZ MOITUZISTCI		EWLETT ACKARD
	NEXT ASSEMBLY	01408	PART NUMBER	
	FINISH	SCALE NONE	D-30140 -	90034-

1	FRONT OF	BAYS (BACKPLANE SIDE)
-	CPU BAY	I/O BAY
1	SSDP-B J3 3040-60092	
	71 9 9	
1	7777777	1
•	MEMORY CPU BACKPLANE (BP) .	1/0 EACKPLANE (B/P)
	(MEM B/P)	
l		
1	_5.2 V52 _5.2 V52	
1	CTLB -2VS	
	10 PINS 92-110	
	J3 J4 J5 GND (AND GND GND SERO YALT BUS . O)	18 J20 J21 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
	ZERO YAT BUS . O	
	JIL JIS JIO JS PDM JII	
	CPU PLENUM	J 17
		I/O PLENUM
1	TO AC UNIT J5 ¢  BAY TEMP J24	
1	AI MODULE AZ MODULE	
	ZET	ZET RET RET DE LA
	(0950-	(0950: 18]
١	BATTERY (655)	
	-5.2V	45.10 V
		DI MODULE 2
	J2 J3 +4/95V R7N RET	
	14 (0950- 8)	
	J4 (0950- 1657) 8 8 AUX	
	AUX AUX	
	8 AUX	XFMR XFMR XFMR
	B MODULE C MODULE	=
-	CPU BAY	I/O BAY





## READER COMMENT SHEET

# Series 64/68 A/B System Block Diagrams and Assembly Drawings Manual

30140-90004

December 1984

We welcome your evaluation of this manual. It is one of several that serve as a reference source for HP 3000 Computer Systems. Your comments and suggestions help us to improve our publications and will be reviewed by appropriate technical personnel. HP may make any use of the submitted suggestions and comments without obligation.

Is this manual technically accurate?	Yes [] No []	(If no, explain under Comments, below.)			
Are the concepts and wording easy to understand?	Yes [] No []	(If no, explain under Comments, below.)			
Is the format of this manual convenient in size, arrangement and readability?	Yes [] No []	(If no, explain or suggest improvements under Comments, below.)			
Comments:					
We appreciate your comments and suggestion U.S. For locations outside the U.S., your lo forwarded.	ns. This form req cal HP representa	uires no postage stamp if mailed in the tive will ensure that your comments are			
	<u> </u>				
Date:					
FROM:					
Name					
Company					
Address					